



INSTALL THE U-BRACKET LOCK INTO THE HOLES OF THE LAST TWO ROWS OF THE OUTER SIDE OF THE SHOE




SLIDE THE LATCH HOLDER WITH THE OPENING FACING TO THE INNER OF THE SHOE OVER THE U-BRACKET LOCK PRESSING SLIGHTLY UNTILL THE END.




INSERT THE CLIP NUMBER 1 WITH THE LEGS FORWARD INTO THE SLOT OF THE LATCH HOLDER PRESSING UNTIL THE LEGS COMPLETELY PAST THROUGH THE BRACKET AND REMAINS ANCHORED.



FOLD EASY LATCH TO ABOUT 35 DEGREES AND WITH THE NAME FACING THE LATCH HOLDER PASS THE 2 RUBBER LACES TRUTH THE OPENING CHANNELS OF THE EASY LATCH AND CLOSE IT.



FLIP EASY LATCH AND WITH THE SLOT FACING UP ANCHOR THE EASY LATCH PET INTO THE LATCH HOLDER, STRETCH THE ELASTIC LACES WITH THE PET ANCHORED IN ITS SUPPORT UNTIL YOUR CHILD IS COMFORTABLE WITH IT BUT THE LACES ARE UNDER TENSION.



ONCE THE RUBBER LACES ARE ADJUSTED INSERT THE CLIP NUMBER 2 WITH THE LEGS FORWARD INTO THE SLOT OF THE EASY LATCH AND PRESS HARD UNTIL THE LEGS ARE ANCHORED.

